



Topcon Receiver Utility (TRU) Release Notes

Version 1.1

©Copyright Topcon Positioning Systems, Inc. February 2009

All contents in this manual are copyrighted by Topcon. All rights reserved. The information contained herein may not be used, accessed, copied, stored, displayed, sold, modified, published, or distributed, or otherwise reproduced without express written consent from Topcon.

Table of Contents

| | |
|--------------------|----------|
| Version 1.1 | 3 |
| Status | 3 |
| Tracking | 5 |
| Positioning | 6 |
| GRS-1 | 7 |
| GMS/GRS Tools | 8 |
| Enable Google Maps | 10 |
| Modem Managing | 11 |
| GMS-2 Pro | 13 |
| Connections | 14 |

Version 1.1

Status

The following information is now displayed by selecting the *Status* icon:



Status

- Position - WGS 84 Coordinates
- Position - GPS Date & Time
- Position - PDOP
- Position - HRMS, VRMS
- List of Satellites
- Sky Plot
- Scatter Plot
- Position in Time

Status

PositionSVs ListSky PlotScatterPosition In Time

2/20/20093:08:20 PM

WGS-84(m)

Standalone

Lat: 39 : 32 : 17.37198 N
Lon: 104 : 54 : 0.70990 W
Alt: 1,799.893 m

PDOP: 2.541

5

0

HRMS 3.426 m

4

1

VRMS 3.658 m

0

0

Close




Status

PositionSVs ListSky PlotScatterPosition In Time

| SVC | USI | EL | AZ | CA | L1P | L2P | L2C |
|-----|-----|-----|-----|----|-----|-----|-----|
| GPS | 2 | 66- | 36 | 47 | 17 | 18 | ?? |
| GPS | 4 | 24- | 56 | 36 | ?? | ?? | ?? |
| GPS | 5 | 61- | 256 | 43 | 5 | 6 | ?? |
| GPS | 10 | 45+ | 160 | 39 | 11 | 10 | ?? |
| GPS | 12 | 67- | 236 | 43 | 23 | 23 | ?? |
| GPS | 30 | 46+ | 298 | 42 | 21 | 22 | ?? |
| GLO | 42 | 57- | 48 | 44 | 42 | 34 | ?? |
| GLO | 43 | 23- | 278 | 39 | 38 | 36 | ?? |
| GLO | 44 | 17- | 96 | 33 | 33 | 35 | ?? |
| GLO | 46 | 14- | 28 | 34 | 34 | 30 | ?? |
| GLO | 48 | 38+ | 320 | 40 | 40 | 29 | ?? |

Close

Page 3




Tracking

The following tracking options are now available by selecting the *Receiver Settings - Tracking* icon:



Tracking

- Antenna Type Selection (Internal/External/Auto)
- Current Input Display (Antenna)
- Elevation Masks (for Satellites Tracking, and Position Computation)
- PDOP Mask for Position Computation



Positioning

The following options are now available by selecting the *Receiver Settings - Positioning* icon:



Positioning

General

- Positioning Mode selection (Standalone, CodeDiff, RTK Float, RTK Fixed)
- Enabling Standalone, and CodeDiff Solutions

SBAS

- WAAS/ENGOS/MSAS Configuring (for both old, and new TG3, and GR3 based receivers)

Positioning

General SBAS

Positioning Mode

☒ Standalone
☐ Code Differential
☐ RTK Float
☐ RTK Fixed

Enable Solutions

☒ Standalone
☐ Code Differential
☒ RTK Float
☒ RTK Fixed

OK Cancel

Positioning

General SBAS

Tracking Satellites (USIs)

☐ 120 ☐ 127 ☐ 134
☐ 121 ☐ 128 ☐ 135
☐ 122 ☐ 129 ☐ 136
☐ 123 ☐ 130 ☐ 137
☐ 124 ☐ 131 ☐ 138
☐ 125 ☐ 132
☐ 126 ☐ 133

Interpret message #0 as:

2

Use Iono Corrections:


Use Sat Only If Available

OK Cancel

GRS-1

Connection

Connection to the internal receiver is accessed by selecting the port settings shown below after selecting *Device - Connect*:



The screenshot shows a software window titled "TRU" with a green header bar. Inside the window, there are three main sections for configuration:





- Connect Using:** A dropdown menu with "Serial Port" selected.
- Port Name:** A text field containing "COM6: (GNSS Port B)" with a small "..." button to its right.
- Receiver Port:** A section containing an unchecked checkbox labeled "External Receiver" and a dropdown menu showing "ser/a".

At the bottom of the configuration area is a large "Connect" button. The window has a standard Windows-style title bar with minimize, maximize, and close buttons.

GMS/GRS Tools


The following tools are available for the GRS-1 receiver by selecting *Device - GMS/GRS Tools*:

- Compass
- Receiver Power Management
- Modem Power Management (GRS-1)



Enable Google Maps

- Configures and enables NMEA Output for Google Maps compatibility. The recommended connection settings are shown below and are the default values.


The screenshot shows a window titled 'TRU' with a green header bar. Inside the window, there are six dropdown menus for configuring NMEA output settings. The settings are as follows:


| Setting | Value |
|---------------|-------|
| Port: | COM7 |
| Baud Rate: | 38400 |
| Data Bits: | 8 |
| Parity: | No |
| Stop Bits: | 1 |
| Flow Control: | None |




At the bottom of the window, there is an 'OK' button.

Modem Managing

- When using TRU with the GRS-1, there is now a *Modem Managing* option accessed from the *Device - Application Mode* menu.
- Select *Connect* and configure the port as shown below to connect to the cellular modem.
- Select the *Settings* icon to view the General information, Settings, and Functions that pertain to the internal modem.



 TRU



Function:

<Select Function>

Execute

Input Parameters:

| Property | Value |
|----------|-------|
| | |
| | |
| | |

Output Parameters:


| Property | Value |
|----------|-------|
| | |
| | |
| | |

General

Settings

Functions

Ok



Cancel

GMS-2 Pro

The following tools are available for the GMS-2 Pro receiver by selecting *Device - GMS/GRS Tools*:

- Compass
- Receiver Power Management
- Camera (GMS-2, GMS-2 Pro)
- LDM (GMS-2 Pro)

Connections

- Connecting to external receivers through the daisy chain of another receiver is now supported.